

BOX COMPONENTS

The following components are included in your OMNI installation package.




OMNI A.L.C.



Mounting Screws (x4)

1 INTEGRATE YOUR VIDEO CARD WITH THE OMNI A.L.C.

Please refer to the enclosed installation addendum to prepare your video card. Each addendum includes detailed instructions on how to install the CoolIT OMNI for your specific video card. Your integrated video card will look like this once it has been assembled onto the OMNI A.L.C. unit.



2 INSTALL THE VIDEO CARD INTO YOUR MOTHERBOARD


Carefully install the video card into the chosen PCIe slot and mount the fan to the rear of your chassis with the four supplied screws. For vertical mounting positions, please ensure that the cupped radiator tanks are placed at the bottom as shown in the photo under Installed Unit (see next page).



3 CONNECT THE OMNI A.L.C. POWER

Connect the 3 PIN power cable to a fan header on your motherboard.

NOTE: The unit requires full power to function properly.



INSTALLED UNIT

The installed OMNI A.L.C. should look like this. Now you can change your video card without changing your cooling solution by simply ordering a new OMNI Interposer Plate to fit your new video card. Each new Interposer Plate comes with custom instructions.



REGISTER YOUR PRODUCT

To activate your warranty please register your product online at www.coolitsystems.com/warranty

WARRANTY INFORMATION

CoolIT Systems Inc. ("CoolIT") warrants each new OMNI A.L.C. against defects in materials or workmanship for a period of two years from the date of purchase, and agrees to repair or replace any defective OMNI A.L.C. without charge. Shipping costs are nonrefundable. This warranty is non-transferable. All warranty claims must be accompanied by the original proof of purchase.

THIS WARRANTY DOES NOT COVER DAMAGE RESULTING FROM ACCIDENT, MISUSE OR ABUSE, LACK OF REASONABLE CARE, SHIPPING DAMAGE, MODIFICATIONS, THE AFFIXING OF ANY ATTACHMENT NOT PROVIDED WITH THE PRODUCT, LOSS OF PARTS, OR OPERATING COMPONENTS AT SPEEDS OR FUNCTIONS OTHER THAN THOSE SPECIFIED BY THEIR MANUFACTURERS.

Use of unauthorized replacement parts or liquid additives will void this warranty. CoolIT will not pay for warranty service performed by a non-authorized repair or diagnostic service and will not reimburse the consumer for damage resulting from warranty service performed by a non-authorized repair service. No responsibility is assumed for any special incidental or consequential damages due to a defective CoolIT product. In order to obtain warranty service, contact our RMA department for information.

The product must be shipped postage prepaid to an authorized CoolIT service location. In order to contact our RMA Dept. please go to: www.coolitsystems.com/support. It is suggested that, for your protection, you return shipments of product by insured mail, insurance prepaid. Damage occurring during shipment is not covered by this warranty. Shipping costs are non-refundable. No other warranty, written or oral, is authorized by CoolIT Systems Inc.

IN NO EVENT SHALL COOLIT OR ITS EMPLOYEES, AGENTS, SUPPLIERS, MANUFACTURERS, OR CONTRACTORS BE LIABLE FOR ANY DAMAGES OF ANY KIND OR CHARACTER, INCLUDING WITHOUT LIMITATION ANY COMPENSATORY, INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, LOSS OF USE, LOSS OF DATA, LOSS OF INCOME OR PROFIT, LOSS OF OR DAMAGE TO PERSONS OR PROPERTY, CLAIMS OF THIRD PARTIES, OR OTHER LOSSES OF ANY KIND OR CHARACTER, AND WHETHER OR NOT THE POSSIBILITY OF SUCH LOSS OR DAMAGE HAS BEEN NOTIFIED TO COOLIT.

CoolIT

SYSTEMS™

CoolIT Systems Inc.
3920 29th Street NE
Calgary, AB Canada
T1Y 6B6

www.coolitsystems.com

US and Canada: 1-866-621-COOL (2665)
International: +1-403-235-4895



INSTRUCTION MANUAL